

ISpire	DOCUMENT NO	XXB-DIS-5132	VER	1.0
	OVLv2 Self-seal Preheat			EFFECTIVE DATE: 10/18/2023
CUSTOMER	/	MODEL NUMBER	5132	
				
Description	Self-sealing disposable			
Features	Food-grade stainless steel center-tube			
	Clog proof design			
	Visible oil chamber can check the remaining oil			
Specifications				
Version(Size)	2.0 ml			
Resistance	1.3Ω			
Fluid Inlet Diameter	φ1.5mm*2			
Wetted Material	Fluid housing	PCTG		
	Atomizer shell and airway tube	Stainless steel		
	Atomizer base	Silicon 55°		
	Heating element	FeCrAl		
	Wick	Ceramic		
	Atomizer retaining wrap	Cotton		
	Seals	Silicon 55°		
Note	Mouthpiece type	Self-sealing mouthpiece (Jig-press)		

ISpire	DOCUMENT NO	XXB-DIS-5132	VER	1.0
	OVLv2 Self-seal Preheat			EFFECTIVE DATE: 10/18/2023
CUSTOMER	/	MODEL NUMBER	5132	
Electrical Specifications		User Interface		
Battery Cell Capacity	320mAh	Charging indication	When charging, the LED will be on. Flash 20 times when the cell is fully charged. LED flash 3 times when plugged out.	
Output Voltage	3.3V	Activation	Button activated & Auto-draw after turn-on	
Max. Current Output	3A	Notification	LED	
Charging Current	0.5A	Low Battery Notification	LED flashes 10 times	
Device Operation				
Operations	Range or Description		Comments	
Power On/Off	Press button 5 times within 2 seconds, flashing 3 times.		N/A	
Power Level Indication	N/A			
Pre-heat function	Press fire button 2 times within 1 seconds. Pre-heat will take 10 seconds to be ready, flashing 5 times.		N/A	
Battery Level Indication	When charging, the LED will be on. Flash 20 times when the cell is fully charged. LED flash 3 times when plugged out.		N/A	

ISpire	DOCUMENT NO	XXB-DIS-5132	VER	1.0
	OVLv2 Self-seal Preheat			EFFECTIVE DATE: 10/18/2023
CUSTOMER	/	MODEL NUMBER	5132	

Filling Instruction

1. With the disposable oriented upside down, insert a conical tipped needle (16 guage recommended) into the self-sealing filling hole (see figure below).

2. Fill the disposable through the needle using a metered filling system, ensuring you do not fill more than the listed capacity.

3. After filling, please remove the conical tipped needle carefully and turn the disposable vertically oriented with the filling hole pointing up.

Failure to follow these instructions may result in disposable leakage or poor performance.

Caution	While filling, do not allow fluid to enter the airway at the center tube. Do not use a blunt tipped or sharp tipped needle as it will damage the self-sealing material and may result in leaking. Damage to the self-sealing material will not be covered by warranty.
----------------	---

